

Mixing and Instructions per use guide:



Questions?
Call or Text us directly at
801-449-1999
or email
info@carpetdetails.com

ALWAYS WATER FIRST THEN ADD POWDER. Always pretest in inconspicuous area for color fastness. ALWAYS slowly pour powder INTO the water. (2 ounce scoop is provided)

Carpet: 2 scoops (4 ounces) per Gallon

In-Line Sprayer: For easier mixing, meter at 1:4 ratio (remove 1:8 yellow tip) and use 6 scoops (12 ounces) per 5 quart container. Otherwise, if using 1:8 yellow tip, use 12 scoops (24 ounces) per 5 quart container.

- 1) Slowly pour powder INTO water (hot water helps it dissolve faster). Shake if necessary to dissolve.
- 2) Pre-spray evenly on carpet paying particular attention to heavy traffic areas, stains, grease, etc. Spray at a rate of about 1 gallon per 300 sq/ft. 3) Best to agitate with rake, bonnet, crb, etc. 4) Let dwell 5 to 10 minutes (its ok if it dries before extraction). 5) Extract with plain cold or hot water through wand. It is not required to extract 100% since whatever is left will continue to encapsulate and clean.
- 6) No acid/neutralizing rinse required.

Upholstery: 1 scoop (2 ounces) per Gallon

- 1) Slowly pour powder INTO water (hot water helps it dissolve faster). Shake if necessary to dissolve.
- 2) Spray lightly directly onto upholstery or onto a towel. 3) Agitate with soft bristle brush or clean towel. 4) No extraction required.

Tile: 2 scoops (4 ounces) per Gallon

- 1) Slowly pour powder INTO water (hot water helps it dissolve faster). Shake if necessary to dissolve.
- 2) Spray/apply onto floor. 3) Let dwell for at least 5 to 10 minutes (it is okay if it dries before cleaning off). 4) Re-wet with water as you scrub and extract with mop, spinner, wet/dry, hose rinse, etc.

Concrete: 2 scoops (4 ounces) per Gallon

- 1) Slowly pour powder INTO water (hot water helps it dissolve faster). Shake if necessary to dissolve.
- 2) Spray/apply onto floor. 3) Let dwell for at least 5 to 10 minutes or as long as possible for deep grease issues. 4) Re-wet with water as you scrub and rinse off.

Spotter: 5 scoops (10 ounces) per Gallon

- 1) Slowly pour powder INTO water (hot water helps it dissolve faster). Shake if necessary to dissolve.
- 2) Apply an ample amount directly on the spot, stain, etc. 3) Agitate in. 4) Let dwell for 1 minute. 5) Blot off. 6) Repeat if necessary.

Encapsulation & Low Moisture: 2 scoops (4 ounces) per Gallon

Bonnet and OP (Oscillating Pad) cleaning:

- 1) Pre-spray evenly on carpet paying particular attention to heavy traffic areas, stains, grease, etc. Spray at a rate of about 1 gallon per 300 sq/ft. 2) Let dwell 10 minutes on greasy areas and high traffic areas. 3) Agitate product into the carpet while lightly rewetting carpet using damp bonnet pads (using a solution tank on floor machine with clean water increases speed dramatically). 4) Use multiple pads to pad out grease areas.

CRB machines with NO solution tank (Brush Pro, etc):

- 1) Pre-spray evenly on carpet paying particular attention to heavy traffic areas, stains, grease, etc. Spray at a rate of about 1 gallon per 300 sq/ft. 2) While carpet is still damp, agitate product into the fibers with CRB machine.

Machines WITH solution tanks (Cimex, Multiwash, etc)

- 1) Apply evenly on carpet through machine's system paying particular attention to heavy traffic areas, stains, grease, etc. 2) Apply at a rate of about 1 gallon per 300 sq/ft. 3) Run clean water or rinse through machine solution tank when finishes.

